

## PPX2450 / PPX2480 compatibility list

| Manufacturer | Device                 | USB Host | CVBS | HDMI | YPbPr | VGA | MHL | Remark   |
|--------------|------------------------|----------|------|------|-------|-----|-----|--|
| Alcatel      | Alcatel one touch 990  | Y        | -    | -    | -     |     |     | USB: use USB Cable and USB Disk on the phone.  |
| Apple        | iPad 1                 | -        | -    | Y    | Y     | y   | -   | HDMI: use Apple HDMI adaptor + standard HDMI cable<br>VGA: use Apple VGA adaptor + PPA 1250<br>YPbPr: use PPA 1280 (select YPbPr Input)                    |
| Apple        | iPad 2                 | -        | -    | Y    | Y     | y   | -   | HDMI: use Apple HDMI adaptor + standard HDMI cable<br>VGA: use Apple VGA adaptor + PPA 1250 (select VGA input)<br>YPbPr: use PPA 1280 (select YPbPr Input) |
| Apple        | iPad 3 (Lightning)     | -        | -    | Y    | -     | y   | -   | HDMI: use Apple Lightning to Digital TV Adapter + standard HDMI cable<br>VGA: use Apple Lightning to VGA Adapter + PPA 1250                                |
| Apple        | iPad 3 (30-pin)        | -        | -    | Y    | Y     | y   | -   | HDMI: use Apple HDMI adaptor + standard HDMI cable<br>VGA: use Apple VGA adaptor + PPA 1250<br>YPbPr: use PPA 1280 (select YPbPr Input)                    |
| Apple        | iPad Mini              | -        | -    | Y    | -     | y   | -   | HDMI: use Apple Lightning to Digital TV Adapter + standard HDMI cable<br>VGA: use Apple Lightning to VGA Adapter + PPA 1250                                |
| Apple        | iPhone 4               | -        | -    | Y    | Y     | y   | -   | HDMI: use Apple HDMI adaptor + standard HDMI cable<br>VGA: use Apple VGA adaptor + PPA 1250 (select VGA input)<br>YPbPr: use PPA 1280 (select YPbPr Input) |
| Apple        | iPhone 4s              | -        | -    | Y    | Y     | y   | -   | HDMI: use Apple HDMI adaptor + standard HDMI cable<br>VGA: use Apple VGA adaptor + PPA 1250 (select VGA input)<br>YPbPr: use PPA 1280 (select YPbPr Input) |
| Apple        | iPhone 5               | -        | -    | Y    | -     | y   | -   | HDMI: use Apple Lightning to Digital TV Adapter + standard HDMI cable<br>VGA: use Apple Lightning to VGA Adapter + PPA 1250                                |
| HTC          | Amaze 4G               | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | EVO 3D                 | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | EVO 4G LTE             | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | EVO View 4G            | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | Flyer                  | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | HTC G12                | Y        | -    | -    | -     | -   | -   | USB: use USB Cable and USB Disk on the phone.  |
| HTC          | HTC G7                 | Y        | -    | -    | -     | -   | -   | USB: use USB Cable and USB Disk on the phone.  |
| HTC          | HTC incredible S S710E | Y        | -    | -    | -     | -   | -   | USB: use USB Cable and USB Disk on the phone.  |
| HTC          | HTC T9188              | Y        | -    | -    | -     | -   | -   | USB: use USB Cable and USB Disk on the phone.  |
| HTC          | Jetstream              | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | One S                  | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | One X                  | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | One XL                 | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | Raider                 | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | Rezound                | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | Sensation              | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | Sensation 4G           | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | Sensation XE           | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |

## PPX2450 / PPX2480 compatibility list

| Manufacturer | Device                  | USB Host | CVBS | HDMI | YPbPr | VGA | MHL | Remark   |
|--------------|-------------------------|----------|------|------|-------|-----|-----|--|
| HTC          | Velocity                | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| HTC          | Vivid                   | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Huawei       | Ascend D quad           | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Huawei       | Ascend DI               | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Huawei       | Ascend DI quad          | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Huawei       | Ascend PI               | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Huawei       | Ascend PI S             | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| LG           | Nitro HD                | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| LG           | Optimus 3D Max          | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| LG           | Optimus 4X HD           | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| LG           | Optimus G               | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| LG           | Optimus LTE II          | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| LG           | Optimus LTE Tag         | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| LG           | Optimus Vu              | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| LG           | Prada                   | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| LG           | Verizon Spectrum        | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Nokia        | Nokia 6120c             | Y        | -    | -    | -     | -   | -   | USB: use USB Cable and USB Disk on the phone.  |
| Nokia        | Nokia E52               | Y        | -    | -    | -     | -   | -   | USB: use USB Cable and USB Disk on the phone.  |
| Nokia        | Nokia N97 Mini          | Y        | -    | -    | -     | -   | -   | USB: use USB Cable and USB Disk on the phone.  |
| Samsung      | Captivate Glide (i927)  | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Samsung      | Epic 4G Touch           | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Samsung      | Galaxy Nexus (i9250)    | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Samsung      | Galaxy Note 5.3"        | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Samsung      | Galaxy S II (i9100)     | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Samsung      | Galaxy S III (i9300)    | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 with included 11-Pin to 5-Pin Micro USB Adapter (available March 2013) |
| Samsung      | Infuse                  | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Samsung      | Samsung Galaxy S I      | Y        | Y    | -    | -     | -   | -   | USB: use USB Cable and USB Disk on the phone.<br>CVBS: use CVBS adapter from Samsung     |
| Sony         | Sony Ericson XPERIA ARC | Y        | -    | -    | -     | -   | -   | Connect with USB and select USB Disk on the phone.                                       |
| Sony         | Xperia GX               | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Sony         | Xperia SX               | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Sony         | Xperia T                | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Sony         | Xperia TX               | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| Sony         | Xperia V                | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| TCL          | ONE TOUCH 997           | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| TCL          | ONE TOUCH 997A          | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| TCL          | ONE TOUCH 997D          | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| TCL          | ONE TOUCH 998           | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |
| TCL          | S800                    | -        | -    | -    | -     | -   | Y   | MHL: use PPA 1240 (available March 2013)   |