

## Installation guide addendum Philips EvoKit LED 2x4 and 2x2 Gen 3

### 0-10 and “SR” models featuring Simpleset Technology

It is now possible to adjust the maximum lumen level of Evokit Gen 3 “0-10” and “SR” models featuring Simpleset technology using a smartphone-based app without requiring power to the Evokit. The app can be downloaded at Google Play. Please contact your Philips representative for the current list of approved Android smartphones.

Using Simpleset technology, you will be able to quickly and easily set specific lumen levels for Evokit 0-10 and SR models. It will provide confirmation of your programming change within seconds.

Evokit Mark 10 (powerline dimming) and StepDim models do not utilize Simpleset Technology.

Distributors can set lumen levels prior to shipping, and contractors can set lumen levels prior to installation. Lumen level is quickly and easily set in two steps

#### Placing the smartphone near the NFC antenna on a driver of Evokit



**Step 1:** Open the smartphone app downloaded at Google Play. Place the smartphone next to the NFC antenna on the driver (small blue rectangular device located at end of the driver, same end as incoming AC power). The phone app will indicate if it has read the settings on the SimpleSet driver.

**Step 2:** Once the app has read the current settings of the driver. Follow the on-screen instructions to select maximum lumen output of Evokit. Place the smartphone next to antenna on the driver and select “program luminaire”. Phone app will confirm changes are made with a “Green” check.

New maximum lumen level is now set. Installation of Evokit can now proceed as normal.

