

PHILIPS

Sensors

EasyAir

PTM215ZE EnOcean
module



Switch Commissioning Procedure

Switch Commissioning Procedure for PTM215ZE EnOcean module




Figure 1 - Outer appearance of PTM215ZE module

This switch contains a PTM215ZE EnOcean module internally as shown in the figure below. For commissioning this switch into a group, the cover need not be removed and you may choose to work with any one of the buttons on the switch.

To add such a switch to a group, ensure that the group is open. Opening of a ZigBee group is possible using EasyAir IR app with either **“Create group”** or **“Add to Group”** options. Once the group is open, follow the steps given below:

1. Long press - Press and hold the chosen button* for 10 seconds
 2. Short press - Press and hold the button* for 1 second
 3. Long press - Press and hold the button* for 10 seconds
 4. Now, perform a series of short presses of 1 second each with the button* until the luminaires blink. This should be done upto a maximum of 16 times and in one of the 16 presses, the channel will coincide with the luminaires and a feedback will be received.
 5. After getting the luminaire feedback, complete the commissioning procedure by making a short press with any of the **other** buttons.
 6. Close the group using EasyAir IR app with **“Close group”** option.
- Now the switch is successfully commissioned and added to the group.

* Irrespective of whether it is single rocker or a dual rocker switch, choose to work with any one of the buttons. However, the same button should be used in case of re-commissioning the switch.

Note: The above procedure also holds for ZigBee channel change. If you change the channel using the IR app, then you have to perform the switch commissioning procedure again.

