



PHILIPS

Descaling using the Built-in Calc Container



1. Set iron's steam control to 'No Steam' and MAX temperature (if your model has a dial)
 2. Fill water tank to MAX, turn on iron and unplug the unit when the light goes out.
 3. Hold iron over the sink and activate CALC CLEAN – this varies by model (see images for different types).
 4. Shake your iron to and fro. Boiling water, steam and scale will come out from the steam vents
 5. When water tank is empty, plug in and clean the soleplate moving your iron across a piece of cloth.
- Repeat process if necessary

Your appliance has been designed to be used with tap water or demineralized water.

Please do not use: perfumed water, vinegar, starch, descaling agents, ironing aids, or other chemicals as they may cause leaking, brown staining, or damage to your appliance.