VersaForm
Recessed LED

Installation Instructions
ID-4xD_VersaForm_Recessed_POE

**Standalone and Air Return configurations**

PHILIPS
◆ LEDALITE

1 Prepare fixtures

Arrange boxed fixtures on the floor in specified mounting locations; remove fixtures and hardware from boxes.

**NOTE:** Leave the cardboard spacers and protective film installed until complete.

x4

Remove fixture from packaging and locate hardware. Leave spacers in place for install.

2 Attach grid clips

CLICK

Attach grid clips to fixture using supplied screws.

3 Install in ceiling grid

Pull down to engage clips onto T-bar.

4 Secure fixture

Secure fixture with grid wire or suitable equivalent per local and national building codes.

5 Connect Ethernet Cable

Insert Ethernet cable into female connector on the top of the luminaire. Each luminaire should have one cable from the POE switch.

6 Remove spacers

Remove spacers and / or protective film.

Cardboard and plastic film are recyclable where facilities exists

Drywall Ceiling ONLY

Structure

Drywall frame kit

Screws supplied by others

For drywall or inaccessible ceilings only:

Lift and shift lens frame, rotating about hinge pins and remove.

Secure fixture to mounting frame by screwing through the holes in side of housing.

! ATTENTION: Install in accordance with national and local building and electrical codes.